









LIVING SPACES


| | | | |
|----------|--------------------|---|------------|
| A | Sofa Legs |  | X4 |
| B | Small screw |  | X16 |
| C | Big screw |  | X8 |
| D | Allen key |  | X1 |



Remove the Sofa legs from the base cloth zipper



GINGER



246455/AS-8011 RFST-GR
 GINGER GREY OTTOMAN
 246452/AS-8011-RFST-BU
 GINGER BUTTERCUP OTTOMAN



Not provided

