LIVING SPACES

OWNER'S MANUAL

JAXON ESPRESSO 2 DRAWER OPEN NIGHTSTAND WITH USB


LIVING SPACES SKU : 292171 VENDOR ITEM NO. : 7YC981C



Scan QR code to view assembly video

ASSEMBLY PARTS LIST

SKU#	IMAGE	DESCRIPTION		HARDWARE KIT PACKED IN BOX SKU: 7YZZCPHW			
				SKU#	IMAGE	DESCRIPTION	QUANTITY
292171-1		2 DRAWER OPEN NIGHTSTAND WITH USB	1	7YZZCPHW-1	(a) xamaanaanaa	ALLEN BOLT (M6 X 50MM)	4
7YC9CPLG	0	LEG	4	7YZZCPHW-2		FLAT WASHER (M6)	4
FULLY AS	SEMBLED			7YZZCPHW-3		ALLEN KEY	1
				RPZZCPTRDQP	25A	TIPPING RESTRAINT	1



PRE-ASSEMBLED PARTS LIST

SKU#	IMAGE	DESCRIPTION	SKU#	IMAGE	DESCRIPTION
7YZZCPHLS		HANDLE	RPZZCPG35BMT		DRAWER GLIDE SET
7YZZCPFC18	6	FOOT CAP	7YZZCPBTS	6	DECORATIVE BOLT
RPZZCPUSBIMT		USB ADAPTER			

LIVING SPACES

OWNER'S MANUAL


JAXON ESPRESSO 2 DRAWER OPEN NIGHTSTAND WITH USB


LIVING SPACES SKU: 292171 VENDOR ITEM NO.: 7YC981C





Scan QR code to view assembly video


ASSEMBLY INSTRUCTIONS











LIVING SPACES

OWNER'S MANUAL

JAXON ESPRESSO 2 DRAWER OPEN NIGHTSTAND WITH USB

LIVING SPACES SKU : 292171 VENDOR ITEM NO. : 7YC981C



Scan QR code to view assembly video



WARNING:

- Maximum distributed load capacity: 135 lbs.
- Drawer capacity: 50 lbs per drawer.
- Sitting, standing or jumping on this product may result in damage or injury.
- Injuries and damage can occur from furniture tip over if product is not properly anchored to the wall. Use the Furniture Tipping Restraint provided with the product. If the Furniture Tipping Restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.

ROUTINE MAINTENANCE:

Periodically check all fittings and tighten if necessary, as they can loosen over time.

CARE AND CLEANING: SOLID WOOD FURNITURE

Congratulations on purchasing this handcrafted solid wood furniture product. Please keep in mind that wood is sensitive to changes in humidity. As the weather changes so does the relative humidity in your home and the moisture content of your solid wood furniture. We have taken every precaution to stabilize the lumber used to build this product. Still, you may observe plank movement or small cracks as the seasons change, particularly during the first 6-12 months of ownership. This is normal for solid wood furniture and will not affect the performance or longevity of this product.

Dust frequently with a clean, damp, lint-free cloth. Frequent dusting will remove abrasive build-up which can damage a finish over time. Avoid using oily polishes or waxes. Avoid exposing your furniture to strong sunlight. Prolonged exposure to direct sunlight can fade the finish of your furniture. Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Do not place hot items on top of surface, always use a mat or other protector. Alcohol, nail polish and perfume are also dangerous, as they can dissolve the furniture finish on contact and may require professional repairs